

WEITZNER

Hanging Instructions

Lineage WLI47

APPLICATION

We recommend Roman® 838 or equivalent clear non-strippable starch based adhesive.

It is advisable to apply the adhesive to the back of the wallcovering using the booking method allowing 3 to 5 minutes for proper set-up time.

Do not get any glue on the face of the wallcovering.

This wallcovering has a repeat pattern.

During installation, line up the seams at eye level and allow the top and bottom of the wallcovering to shift if necessary. Depending on the repeat, trimming & butting or a double cut might be necessary to match at seams.

To avoid fraying, use a new blade for each cut and lay the wallcovering down with a soft brush or wallcovering installation tool.

Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.

RECOMMENDATIONS

Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers near you please visit www.wallcoveringinstallers.org.

Always make sure the surface you are hanging on has been properly prepared. Walls should be clean, smooth, dry and structurally sound. Repair any holes or flaws in the walls prior to installing wallcovering.

Make sure your tools, hands and workspace are always clean. Please handle with care, never crease the wallcovering and avoid touching the face.

We recommend priming walls before installing the wallcovering

using Zinsser® Shieldz® or equivalent. Do not hang wallcovering directly on an oil-based primer.

Always apply an even coat of paste to either the wall or the back of the wallcovering. If you choose to apply the paste directly to the back of the wallcovering, handle with care during installation.

Always use a new blade for each cut and take care not to overwork or stretch seams.

After installing a maximum of three sheets, inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

Note: The manufacturer assumes no responsibility for installation of material beyond three sheets and will not be held responsible for labor under any circumstances.

For product specifications and installation videos, please visit www.weitznerlimited.com.

CARE INSTRUCTIONS

Liquid stains should be removed immediately by blotting using a clean, dry white cloth.

Regular vacuuming with a soft brush attachment may be used to remove dust deposits.