

WEITZNER

Hanging Instructions

Stratum WST124

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org

WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

ADHESIVE:

- We recommend Roman® ECO-778 or equivalent clay-based adhesive.
- Apply a moderate amount of adhesive to the back of the wallcovering. Allow 3-5 minutes for adhesive to properly set up before installing.
- Remove any excess glue at the seams with a soft, clean, white cloth.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.

TRIMMING:

- The edges of this wallcovering are factory trimmed.
- The factory trimmed edges of this product easily butt together. If you need to trim this product, we recommend trimming a clean seam on your work table using a utility knife and a straight edge.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut.

CONTINUED >

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

WEITZNER

Hanging Instructions

Stratum WST124

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org

REPEAT:

- This wallcovering is natural stone and has no repeat.

RECOMMENDATIONS:

- Use a template if installing this wallcovering in a pattern or block. Use a plumb line when installing this wallcovering.
- This product installs in a similar method to ceramic tiles. Apply the adhesive to the back of the tile, and adhere it to the wall.
- Use a wallcovering installation tool to gently work out any air bubbles to ensure positive contact between the tile and wall.
- Smoothing should be done from the middle of the wallcovering, working toward the outside edge.
- Fingerprints can permanently stain this stone surface; latex gloves should be worn when handling this product.

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.