

# WEITZNER

## Hanging Instructions

### Galena W5007

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)

#### WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

#### WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

#### ADHESIVE:

- For Weitzner Clean Vinyl wallcoverings, we recommend Roman® ECO-788 or equivalent clay-based adhesive.
- Wet Hang: For this hanging method, the adhesive can be diluted with water according to the manufacturer's instructions. Apply a liberal, even coat of adhesive over the entire back of the wallcovering with either a commercial pasting machine or a roller. Allow the material to book for 15 minutes before installation.
- Dry Hang: For this hanging method, do not dilute the adhesive. Roll a liberal, even coat of the full-strength adhesive on the wall and apply the wallcovering.
- For difficult installations, such as columns or outside corners, apply the adhesive to both the wall and the back of the wallcovering and allow each surface to tack up before installation.

#### TRIMMING:

- The edges of this wallcovering are factory trimmed.
- We recommend trimming a clean, straight edge on your work table and butting the seams of this wallcovering to achieve the correct side match.
- Alternately, you may double cut this wallcovering.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.

**CONTINUED >**

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

# WEITZNER

## Hanging Instructions

### Galena W5007

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)

- Always use a new, very sharp blade for each cut.

#### REPEAT:

- This wallcovering has an all-over repeat pattern, and is not intended to match at the seams.

#### RECOMMENDATIONS:

- If you decide to hang multiple drops of this wallcovering, they should be trimmed and reverse hung.
- Do not use steel-blade knives for smoothing the wallcovering or seams, as the steel will damage the vinyl surface.
- The wallcovering must be allowed to warm up to a minimum of 70°F (21°C) before installation.
- This wallcovering can be made permeable by a micro-venting process (minimum 8+ perms). However, permeable wallcovering cannot compensate for water intrusion caused by poor building design, faulty construction, building-system failure or improper maintenance practices.
- To prevent discolored seams and dull areas on the face of this wallcovering, it is important to carefully wash the excess adhesive from seams after installing each strip. Use a sponge dampened with clean, warm water, changed frequently, and dry with a clean, soft towel.

- Vinyl wallcovering can act as a vapor barrier and consequently should not be installed on walls that are susceptible to excessive condensation or moisture infiltration.
- Affix the wallcovering to the wall using a soft brush or wallcovering installation tool, and gently work out any air bubbles or wrinkles. Smoothing should be done from the middle of the wallcovering, working toward the outside edge.

#### CARE INSTRUCTIONS:

- Please see additional cleaning and warranty information for Weitzner's Clean Vinyl wallcoverings on the following page.
- Existing mold or mildew must be removed from walls, followed by treatment to inhibit further growth. Refer to the EPA website for guidelines at [www.epa.gov](http://www.epa.gov).

#### SPECIAL NOTES:

- \$3.00/yard additional fee for orders below 30 yards. IMO requirement must be specified with order, minimums vary.

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.