# WEITZNER

# Hanging Instructions Aquarelle W1087

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit <a href="www.wallcoveringinstallers.org">www.wallcoveringinstallers.org</a>

# WALLCOVERING PREPARATION:

- Do you have the right amout of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a maximum of 3 sheets, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

#### WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

# **ADHESIVE:**

- We recommend a mixture of Roman® 880 and Roman® 838, or equivalent adhesive.
- It is advisable to apply adhesive to the back of the wallcovering using the booking method, allowing 3 to 5 minutes for proper set-up time.

# TRIMMING:

- The edges of this wallcovering are factory trimmed.
- We recommend trimming a clean, straight edge on your work table and butting the seams of this wallcovering.
- We do not recommend double cutting this wallcovering.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut.

#### REPEAT:

- W 37" H 36 1/4"
- This wallcovering has an all-over repeat pattern, and is not intended to match at the seams

### **CONTINUED >**

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.



# Hanging Instructions Aquarelle W1087

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org

# **RECOMMENDATIONS:**

• If you decide to hang multiple drops of this wallcovering, they should reverse hung.

### **CARE INSTRUCTIONS:**

 Liquid stains should be removed immediately by blotting with a clean, damp, white cloth. Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

PAGE 2 ■