

WEITZNER

Hanging Instructions

Calculus W1094

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org

WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

ADHESIVE:

- We recommend a mixture of Roman® 880 and Roman® 838, or equivalent adhesive.
- Apply a moderate amount of adhesive to avoid over-saturating the wallcovering. Allow 3-5 minutes for adhesive to properly set up before installing.
- Remove any excess glue at the seams with a soft, clean, white cloth.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.

TRIMMING:

- The edges of this wallcovering are factory trimmed.
- The factory trimmed edges of this product easily butt together. If you need to trim this product, we recommend trimming a clean seam on your work table using a utility knife and a straight edge.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.

CONTINUED >

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

WEITZNER

Hanging Instructions Calculus W1094

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org

REPEAT:

- W 16" H 16"

RECOMMENDATIONS:

- This product installs in a similar method to ceramic tiles. Apply the adhesive to the back of the tile, and adhere it to the wall.
- Use a wallcovering installation tool to gently work out any air bubbles to ensure positive contact between the tile and wall.
- Smoothing should be done from the middle of the wallcovering, working toward the outside edge.

CARE INSTRUCTIONS:

- Liquid stains should be removed immediately by blotting with a clean, dry, white cloth. Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

SPECIAL NOTES:

- Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.
- Due to the handmade technique, variations in color and/or texture may occur. CFA not available.
- **1 box contains (6) 16" x 16" tiles.**