

WEITZNER

Hanging Instructions

Manor W9035

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org
View the hanging instructions video at www.weitznerlimited.com/videos/leather-suedes

WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

ADHESIVE:

- We recommend Roman® 838 or equivalent clear, non-strippable, starch-based adhesive.
- It is advisable to apply adhesive to the back of the wallcovering using the booking method, allowing 3 to 5 minutes for proper set-up time.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.

TRIMMING:

- The edges of this wallcovering are not factory trimmed, and there is a selvage of approximately 3".
- We recommend trimming a clean, straight edge on your work table and butting the seams of this wallcovering.
- We do not recommend double cutting any of our faux leather wallcoverings.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut to avoid fraying.

CONTINUED >

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

WEITZNER

Hanging Instructions

Manor W9035

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org
View the hanging instructions video at www.weitznerlimited.com/videos/leather-suedes

REPEAT:

- W 5" H 5"
- This wallcovering has a straight-match repeat pattern. To achieve a perfect repeat match at eye level, we recommend seaming in the middle of the X, and allowing the top and bottom of the wallcovering to shift if necessary.
- Due to the quilting technique, the repeat may not perfectly match along the whole seam.
- We recommend lining up the repeat at eye level and allowing the top and bottom of the wallcovering to shift if necessary.
- Remove liquid stains immediately with clean water, mild soapy water or a 1:1 solution of water and white vinegar. Remove the excess soap or vinegar solution by blotting with a clean, white, dry cloth. "Rings" that appear after drying are usually the result of residual cleaning solution and can be removed by cleaning again with water.
- Remove non-water soluble stains such as grease or oil with a petroleum-based solvent. Blot the stained area with a clean cloth dampened with solvent and then with a clean, dry cloth. To avoid enlarging the stain, work from the edges toward the center. This wallcovering can be maintained with lint brush and light stains and smudge marks can be removed with Scotch tape or eraser.
- Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

RECOMMENDATIONS:

- If you decide to hang multiple drops of this wallcovering, they should be trimmed and hung as they are unrolled. It is not recommended to reverse hang this wallcovering.
- To avoid fraying, take care not to overwork the seam.
- Affix the wallcovering to the wall using a soft brush or wallcovering installation tool, and gently work out any air bubbles or wrinkles. Smoothing should be done from the middle of the wallcovering, working toward the outside edge.

SPECIAL NOTES:

- Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.
- CFA not available.

CARE INSTRUCTIONS:

PAGE 2 ■

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.