

WEITZNER

Hanging Instructions

Stratum W9064

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org
View the hanging instructions video at www.weitznerlimited.com/videos/stone

WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

ADHESIVE:

- We recommend Roman® ECO-778 or equivalent clay-based adhesive.
- Apply a moderate amount of adhesive to the back of the wallcovering. Allow 3-5 minutes for adhesive to properly set up before installing.
- Remove any excess glue at the seams with a soft, clean, white cloth.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.

TRIMMING:

- The edges of this wallcovering are factory trimmed.
- The factory trimmed edges of this product easily butt together. If you need to trim this product, we recommend trimming a clean seam on your work table using a utility knife and a straight edge.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut.

CONTINUED >

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

WEITZNER

Hanging Instructions

Stratum W9064

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org
View the hanging instructions video at www.weitznerlimited.com/videos/stone

REPEAT:

- W 0" H 0"
- This wallcovering is natural stone and has no repeat.

RECOMMENDATIONS:

- Fingerprints can permanently stain this stone surface; latex gloves should be worn when handling this product.
- This product is sold unsealed. Sealing this product after installation is highly recommended. The sealant should be applied at least 24 hours after completing installation to ensure that the wallcovering has properly cured. Sealants may slightly darken the color of the material.
- Weitzner recommends Porous Plus and Bullet Proof high quality sealants. Follow all directions from sealant manufacturers carefully.
- Weitzner is not liable for issues related to the application of sealants.
- If left unsealed, contact with oils from the skin can permanently stain this product.
- This wallcovering is not recommended for use in kitchens or bathrooms.
- Use a template if installing this wallcovering in a pattern or block. Use a plumb line when installing this wallcovering.
- Apply the adhesive to the back of the tile, and adhere it to the wall.
- Use a wallcovering installation tool to gently work out any

air bubbles to ensure positive contact between the tile and wall.

- Smoothing should be done from the middle of the wallcovering, working toward the outside edge.

CARE INSTRUCTIONS:

- Liquid stains should be removed immediately by blotting with a clean, dry, white cloth. Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

SPECIAL NOTES:

- The face of this material is composed of natural stone. Color and pattern variations will occur from panel to panel.
- In the event that the seams do not perfectly align, use a high quality paint or tinted primer that matches the color of the wallcovering.
- Do not hang wallcovering directly on an oil based primer.
- Due to the natural stone material, applying an appropriate sealant is highly recommended after installation
- Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.