

# WEITZNER

## Hanging Instructions

### Cumulus W1007

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)  
View the hanging instructions video at [www.weitznerlimited.com/videos/panels](http://www.weitznerlimited.com/videos/panels)

#### WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

#### WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

#### ADHESIVE:

- We recommend a mixture of Roman® 880 and Roman® 838, or equivalent adhesive.
- If a painted wall is used behind this open-work pattern, it is important to use a high quality latex paint. Allow the paint to dry completely and cure for at least 24 hours before adhering the wallcovering.
- Lay down a plastic liner. You will paste and cut the wallcovering directly on top of this liner. Cut wallcovering and plastic liner cleanly, using a straight edge and new blade for each cut. Take care not to overwork the material. Carefully lift wallcovering and liner paper from work table and apply adhesive.
- Apply wallcovering and liner paper to the wall using even strokes and moderate pressure. Trim excess material with a straight edge and fresh blade. Carefully peel back the liner from wallcovering and adhere pasted wallcovering to the wall.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.
- This paper stretches when moistened, and should be handled as little as possible during installation.

**CONTINUED >**

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

# WEITZNER

## Hanging Instructions

### Cumulus W1007

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)  
View the hanging instructions video at [www.weitznerlimited.com/videos/panels](http://www.weitznerlimited.com/videos/panels)

#### TRIMMING:

- The edges of this wallcovering are not factory trimmed.
- If you decide to trim this pattern to install multiple drops, we recommend trimming a clean, straight edge on your work table and butting the seams of this wallcovering.
- We do not recommend double cutting any of our handmade papers.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut.
- Alternatively, you may overlap the pattern to create a continuous repeat.

#### REPEAT:

- This wallcovering has an all-over, random repeat pattern.

#### RECOMMENDATIONS:

- If you decide to hang multiple drops of this wallcovering, they should be trimmed and hung as they are unrolled. It is not recommended to reverse hang this wallcovering.

- Affix the wallcovering to the wall using a soft brush or wallcovering installation tool, and gently work out any air bubbles or wrinkles. Smoothing should be done from the middle of the wallcovering, working toward the outside edge.

#### CARE INSTRUCTIONS:

- Liquid stains should be removed immediately by blotting with a clean, dry, white cloth. Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

#### SPECIAL NOTES:

- Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.
- This wallcovering has been treated with a stain-resistant finish.
- CFA not available. Due to the handmade technique, variations in color and/or texture may occur.