

WEITZNER

Hanging Instructions Around the World W1011

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org
View the hanging instructions video at www.weitznerlimited.com/videos/papers

WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

ADHESIVE:

- We recommend Roman® 838 or equivalent clear, non-strippable, starch-based adhesive.
- It is advisable to apply adhesive to the back of the wallcovering using the booking method, allowing 3 to 5 minutes for proper set-up time.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.

TRIMMING:

- The edges of this wallcovering are not factory trimmed.
- We recommend trimming a clean, straight edge on your work table and butting the seams of this wallcovering.
- We do not recommend double cutting any of our handmade papers.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut to avoid fraying.

CONTINUED >

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

WEITZNER

Hanging Instructions Around the World W1011

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit www.wallcoveringinstallers.org
View the hanging instructions video at www.weitznerlimited.com/videos/papers

REPEAT:

- This wallcovering has an all-over, random repeat pattern, and should panel when installed.

RECOMMENDATIONS:

- If you decide to hang multiple drops of this wallcovering, they should be trimmed and hung as they are unrolled. It is not recommended to reverse hang this wallcovering.
- For added durability and water resistance in bathrooms, kitchens and other high traffic areas, custom surface lamination is recommended.
- To avoid fraying, take care not to overwork the seam.
- Affix the wallcovering to the wall using a soft brush or wallcovering installation tool, and gently work out any air bubbles or wrinkles. Smoothing should be done from the middle of the wallcovering, working toward the outside edge.

CARE INSTRUCTIONS:

- Liquid stains should be removed immediately by blotting with a clean, dry, white cloth. Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

SPECIAL NOTES:

- These are real recycled, handwoven maps. The color and text will vary within the roll and from roll to roll.
- This wallcovering has been treated with a stain-resistant finish.
- Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.
- Due to the handmade technique, variations in color and/or texture may occur.