# WEITZNER

# Hanging Instructions Aya W1024

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit <a href="www.wallcoveringinstallers.org">www.wallcoveringinstallers.org</a>
View the hanging instructions video at <a href="www.weitznerlimited.com/videos/paperbacked-fabric">www.weitznerlimited.com/videos/paperbacked-fabric</a>

### WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a maximum of 3 sheets, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

#### WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

### **ADHESIVE:**

- We recommend Roman® 838 or equivalent clear, nonstrippable, starch-based adhesive.
- It is advisable to apply adhesive to the back of the wallcovering using the booking method, allowing 3 to 5 minutes for proper set-up time.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.

## TRIMMING:

- The edges of this wallcovering are factory trimmed.
- We do not recommend double cutting any of our handmade papers.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut to avoid fraying.

#### **CONTINUED >**

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.



# Hanging Instructions Aya W1024

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit <a href="www.wallcoveringinstallers.org">www.wallcoveringinstallers.org</a>
View the hanging instructions video at <a href="www.weitznerlimited.com/videos/paperbacked-fabric">www.weitznerlimited.com/videos/paperbacked-fabric</a>

### **REPEAT:**

 This wallcovering does not have a repeat pattern and should panel when installed.

#### **RECOMMENDATIONS:**

- If you decide to hang multiple drops of this wallcovering, they should be trimmed and hung as they are unrolled. It is not recommended to reverse hang this wallcovering.
- Affix the wallcovering to the wall using a soft brush or wallcovering installation tool, and gently work out any air bubbles or wrinkles. Smoothing should be done from the middle of the wallcovering, working toward the outside edge.
- To avoid fraying, take care not to overwork the seam.

#### **CARE INSTRUCTIONS:**

 Liquid stains should be removed immediately by blotting with a clean, dry, white cloth. Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

### **SPECIAL NOTES:**

- This wallcovering has been treated with a stain-resistant finish.
- Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.
- Due to the handmade technique, variations in color and/or texture may occur.

PAGE 2 ■