

# WEITZNER

## Hanging Instructions

### Byzantine W1078

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)  
View the hanging instructions video at [www.weitznerlimited.com/videos/vinyl](http://www.weitznerlimited.com/videos/vinyl)

#### WALLCOVERING PREPARATION:

- Do you have the right amount of wallcovering yardage? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the wallcovering, and avoid touching the face.
- Inspect the wallcovering before installing to ensure it is free from defects.
- Install a **maximum of 3 sheets**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

#### WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

#### ADHESIVE:

- For Weitzner Clean Vinyl wallcoverings, we recommend Roman® ECO-788 or equivalent clay-based adhesive.
- Wet Hang: For this hanging method, the adhesive can be diluted with water according to the manufacturer's instructions. Apply a liberal, even coat of adhesive over the entire back of the wallcovering with either a commercial pasting machine or a roller. Allow the material to book for 15 minutes before installation.
- Dry Hang: For this hanging method, do not dilute the adhesive. Roll a liberal, even coat of the full-strength adhesive on the wall and apply the wallcovering.
- To prevent discolored seams and dull areas on the face of this wallcovering, it is important to carefully wash the excess adhesive from seams after installing each strip. Use a sponge dampened with clean, warm water, changed frequently, and dry with a clean, soft towel.
- For difficult installations, such as columns or outside corners, apply the adhesive to both the wall and the back of the wallcovering and allow each surface to tack up before installation.

#### TRIMMING:

- The edges of this wallcovering are factory trimmed.
- We recommend trimming a clean, straight edge on your work table and butting the seams of this wallcovering.

**CONTINUED >**

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

# WEITZNER

## Hanging Instructions

### Byzantine W1078

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)  
View the hanging instructions video at [www.weitznerlimited.com/videos/vinyl](http://www.weitznerlimited.com/videos/vinyl)

- We do not recommend double cutting any of our Mylar wallcoverings.
- Take care not to scratch the Mylar surface during installation.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.
- Always use a new, very sharp blade for each cut.
- To prevent wrinkling, we recommend cutting a seam at inside corners.
- For outside corners, always carry the wallcovering 6" around the corner then trim excess material from base moldings, door and window frames with a new, sharp razor blade and cutting guide.
- Special attention should be given to outside corners to make sure the corner edges are straight and level without waves or bows.

#### REPEAT:

- W 18" H 27"
- This wallcovering has an all-over repeat pattern, and is not intended to match at the seams.

#### RECOMMENDATIONS:

- If you decide to hang multiple drops of this wallcovering, they should be trimmed and reverse hung.
- This wallcovering can act as a vapor barrier and should not be installed on walls that are susceptible to excessive

condensation or moisture infiltration. Walls must be completely dry and free of any indications of prior mold/mildew growth before installation.

- Mylar-laminated wallcovering can accentuate imperfections on the wall if the surface is not properly prepared.
- This wallcovering cannot be micro-vented, as this will change the appearance of the design.
- Affix the wallcovering to the wall using a soft brush or wallcovering installation tool, and gently work out any air bubbles or wrinkles. Smoothing should be done from the middle of the wallcovering, working toward the outside edge.

#### CARE INSTRUCTIONS:

- Never use abrasive cleansers or steel wool as they will mar the surface. Do not use solvents such as nail polish remover as they will remove the topcoat finish.
- Ordinary dirt and smudges can be removed by using a mild soap, warm water and light pressure with a sponge or cloth. Stains should be removed as quickly to eliminate any possible reaction between the staining agent and wallcovering.

#### SPECIAL NOTES:

- The wallcovering must be allowed to warm up to a minimum of 70°F (21°C) before installation.
- \$3.00/yard additional fee for orders below 30 yards.

**CONTINUED >**

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

# WEITZNER

## Mylar Vinyl Wallcovering Cleaning and Maintenance Instructions

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)  
View the Mylar Vinyl wallcovering hanging instruction video at [www.weitznerlimited.com/videos/vinyl](http://www.weitznerlimited.com/videos/vinyl)

### SPECIAL NOTES

- When wallcovering is wet use caution with items that may scratch the surface.
- Never use abrasive cleansers or steel wool as they will mar the surface. Do not use solvents such as nail polish remover as they will remove the topcoat finish.
- This wallcovering is finished with water-based protective top coating for enhanced cleanability.
- The following general cleaning instructions should serve as a guide for normal maintenance practices.
- For more difficult stains that are only surface deep, the use of a stronger detergent such as Fantastic, Formula 409 or similar non-abrasive household cleaner or isopropyl (rubbing) alcohol is recommended. Stains should be removed as quickly as possible to eliminate any possible reaction between the staining agent and wallcovering. Timeliness is especially important for removing stains that contain colorants or solvents. Use these cleaning agents with a sponge or cloth and light pressure.
- When using rubbing alcohol, first test on an inconspicuous area.
- Never mix cleaning agents together – toxic vapors may be produced.

### CLEANING INSTRUCTIONS

- Ordinary dirt and smudges can be removed by using a mild soap, warm water and light pressure with a sponge or cloth. Never use abrasive cleansers or steel wool as they will mar the surface. Do not use solvents such as nail polish remover as they will remove the topcoat finish.
- We recommend cleaning with Liquid Sunshine, made by Vermont Soap Organics, a non-toxic cleaner made with organic oils. If this is not easily attainable, any organic soap will suffice. Rinse thoroughly from the top of the wall down using clean water and a clean sponge (change and rinse water often).
- Dry the wallcovering with a soft, lint-free cloth or towel. Repeat, if necessary.

### SANITIZING CARE

- Virex® Tb commercial cleaning solution can be used on this wallcovering. When used as directed, this one step cleaner, deodorizer and disinfectant demonstrates proven resistance to damage even after multiple cleanings.
- The use of a dilute solution (5%) of chlorine bleach is acceptable for sanitization purposes. It is important to limit the set time and dry the surface after sanitization is complete. Test a small inconspicuous area prior to cleaning to ensure there will be no damage to the wallcovering.

---

Weitzner assumes no responsibility for installation of material beyond 3 sheets and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.