

# WEITZNER

## Hanging Instructions

### Mason W1080

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)  
View the hanging instructions video at [www.weitznerlimited.com/videos/tiles](http://www.weitznerlimited.com/videos/tiles)

#### WALLCOVERING PREPARATION:

- Do you have the right number of tiles? If not, stop and contact your local sales representative.
- Make sure your tools, hands and workspace are clean.
- Never crease the tile, and avoid touching the face.
- Inspect tile before installing to ensure it is free from defects.
- Install a **maximum of 18 tiles**, then inspect application. If satisfactory, continue. If not, discontinue and contact your local sales representative.

#### WALL PREPARATION:

- Make sure the surface you are hanging on has been properly prepared.
- Walls should be clean, smooth, dry and structurally sound.
- Repair any holes or flaws in the walls prior to installing wallcovering.
- We recommend priming walls before installing the wallcovering using Zinsser® Shieldz® or equivalent wallcovering-specific primer.
- Do not hang wallcovering directly on an oil-based primer.

#### ADHESIVE:

- We recommend a mixture of Roman® 880 and Roman® 838, or equivalent adhesive.
- Apply a moderate amount of adhesive to avoid over-saturating the wallcovering. Allow 3-5 minutes for adhesive to properly set up before installing.
- Take care not to get any glue on the face of the wallcovering. If glue does get on the face of the wallcovering, immediately blot with a dry, clean, white cloth.
- Remove any excess glue at the seams with a soft, clean, white cloth.

#### TRIMMING:

- The edges of the tiles are factory trimmed.
- The factory trimmed edges of this product easily butt together. If you need to trim this product, we recommend trimming a clean seam on your work table using a utility knife and a straight edge.
- Trim material at the ceiling, baseboard, windows and doors with a single-edged razor blade.

**CONTINUED >**

Weitzner assumes no responsibility for installation of material beyond 3 tiles and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.

# WEITZNER

## Hanging Instructions

### Mason W1080

Do not cut or install until you have read these instructions. Weitzner recommends hiring a professional wallcovering installer. For a list of professional installers, please visit [www.wallcoveringinstallers.org](http://www.wallcoveringinstallers.org)  
View the hanging instructions video at [www.weitznerlimited.com/videos/tiles](http://www.weitznerlimited.com/videos/tiles)

#### REPEAT:

- W 16" H 16"

#### INSTALLATION:

- You can install this pattern in one direction, as a checkerboard or in a mitered design.
- Apply the adhesive to the back of the tile and adhere it to the wall.
- Use a wallcovering installation tool to gently work out any air bubbles to ensure positive contact between the tile and wall.
- Smoothing should be done from the middle of the tile, working toward the outside edge.

#### CARE INSTRUCTIONS:

- Liquid stains should be removed immediately by blotting with a clean, dry white cloth. Regular vacuuming with a soft brush attachment may be used to remove dust deposits.

#### SPECIAL NOTES:

- Not guaranteed against fading or color change. Avoid direct or brilliantly reflected sunlight.
- Due to the handmade technique, variations in color and/or texture may occur. CFA not available. 1 box contains (6) 16" x 16" tiles.
- If desired, Mason may be painted after installation using standard painting tools/techniques (such as brush, roller or spray) and interior paint (including oil-based, acrylic-based or latex-based). It is recommended to use primer appropriate for the chosen paint. A slight change in texture may occur and will be minimized by using a spray technique.

---

Weitzner assumes no responsibility for installation of material beyond 3 tiles and will not be held responsible for labor under any circumstances. For any questions, contact your local representative.